



Dyson v6 Absolute Filter Replacement

Replace the HEPA filter located at the top of the Dyson v6 Absolute. The filter must be regularly cleaned and checked for blockages.

Written By: Tabitha Espina Velasco



INTRODUCTION


The Dyson v6 Absolute is cordless, bagless, and can be converted into a handheld vacuum cleaner when the wand is removed. Its HEPA filtration ensures powerful suction, careful removal of dust and allergens, and easy replacement for regular cleaning.

Step 1 — Filter



- Unplug the device.
- Set the device upright on its base.

Step 2



- Locate the blue knob labeled "Filter" at the center of the cyclone.

Step 3



- Loosen the filter by twisting the knob.
- Once loose, pull the filter up and out of the cyclone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 02:42:48 PM.